

The LWA Unit Functions

To activate an SOS alert

Push and hold the centre button for six (6) seconds.

Once the SOS button has been activated, the Following will occur:

- The centre **Red light** will start to rapidly flash
- An SMS containing, the last known GPS location and a **HELP** message with time and date is sent to the **24/7 Incident Response Centre (IRC)**.
- The unit will discreetly "Beep" once indicating the unit is in alarm and dialling the IRC to initiate a 2 way voice call
- The unit will then discreetly "Beep" twice indicating a two way voice call has been established an experienced Security Operator is now monitoring the situation, recording what is being said and will act accordingly to your situation
- **PROVIDE SPECIFIC INFORMATION RELATING TO YOUR SITUATION WHERE POSSIBLE.**

