

The LWA Unit Functions

Stop N Drop

Depending on your environment you may have an automatic activated device that is activated through registration of impact – either through sudden “Stop or Drop” (SnD)

Once the device registers an impact that exceeds its adjustable programmed limit, the device will automatically activate as per the SOS button, with the following occurring without any interaction required.

- An SMS containing, the last known GPS location and a “Stop /Drop” message with time and date is sent to the 24/7 IRC.
- The unit will “Beep” once indicating the unit is in alarm and dialling the IRC to initiate a 2 way voice call
- The unit will then “Beep” twice indicating a two way voice call has been established an experienced Security Operator is now monitoring the situation, recording what is being said and will act accordingly to your situation
- If nothing is heard, emergency procedures are instigated in line with the client’s policies and procedures provided.

