

## Updating your location

Although the LWA-SOS is able to obtain your GPS location, your **GPS location is not updated automatically**, this done manually as the user needs or when an alert is activated.

We do not want to track your movements without your consent, so it is important that you take some responsibility for your own safety and update your location regularly.

The more up to date information we have, the better we can help you when you need.

Press the ON / Off button for 2 seconds or until then **Blue** LED starts to flash rapidly.  
Release the button  
Unit will now look for current location and send SMS message to IRC with GPS co-ordinate details.

How easy is that !

